3. Power Supply

Written By: Ryan Lock

Step 1 — Power Supply Wiring

- At this stage your PSU-Output-Power-Cable will be inserted inside the Y-Axis Drag Chain.
  - Place the Power Supply at the Rear of the WorkBee CNC Machine next to this cable.
- Use the red switch on the side select the input voltage for your local power.
- Plug the PSU-Output-Power-Cable into the female connector on the Pre-Assembled Power Supply.
- Plug the mains cable into the IEC Inlet on the Pre-Assembled Power Supply.

⚠ Do not plug the mains cable into your wall socket at this point.

Thanks for following the guide. Any issues, please contact us!