Raised Toilet Seat with Lid

Roma, 100mm

Please read this user manual before using the Roma Raised Toilet Seat.

This product raises toilet seat height by 100mm.

Safety Information

Visual inspection

Inspect the product regularly. Check to ensure that material is free from damage.

Before use

Ensure that the product is correctly mounted/installed. Be sure that adjustment knobs on sides of seat are tight.

Information instructions

Remove toilet seat and lid from toilet. Turn both locking clamps counter clockwise until they can no longer turn. This will open the locking devices. Place the toilet raiser on the toilet. Be sure the two locking brackets are on both sides of the toilet and that the raiser is flush with the toilet. Turn the locking brackets clockwise until tight. Hand tighten only. Do not use tools as threads on the adjustment bracket may strip.

Removal instructions

Rotate knobs counter clockwise until seat is loose. Lift front of toilet raiser and pull forward to remove.

Using the product

The toilet raiser increases the height of a toilet by 100mm. User's weight should be centred over toilet seat.

Warning

- Do not load the seat surface on one side only.
- Under no circumstance stand on the seat.

Material

Plastic

Care of product

Clean regularly with normal household detergent. Do not use aggressive cleaners.

Expected lifetime

Up to 10 years of normal use.

Technical information

Material	Plastic
Total depth	412 mm
Total height	155 mm
Raiser	100 mm
Hygiene cutouts	In front and back
Toilet opening, width x length	200 mm x 270 mm
Weight	1.5 kg
Max. user weight	130 kg

This product is distributed by:

unicare.au

info@unicare.au

1800 656 654

25-29 Alexandra Place, Bentley, WA 6102